

7707 Fire 2.0 Software Update: 4-Step User Guide

Prior to updating your unit please make note of your Subscriber ID (account number) and Cipher Code.

1

Insert the flash drive into either one of the two USB ports inside the Subscriber.

2

Press the reset button.

- The Subscriber is now performing the software update. The LCD screen will show, "**POWERED BY AES SYSTEM BOOTING UP...**" followed by, "**UPDATING SYSTEM FLASH PLEASE WAIT**".



Do not remove flash drive from the USB port when message, "**SYSTEM FLASH UPDATED REMOVE USB AND RESET**" populates.



SYSTEM FLASH UPDATED
REMOVE USB AND RESET

3

Return to the inside of the panel and press the reset button for the second time.

- The Subscriber is now performing the software update. This will take approximately 5 minutes.

Once completed you will see, "**UPDATE COMPLETE REMOVE USB AND RESET**".

4

Remove the flash drive from the USB port and press the reset button for the final time.

- The unit will reboot and finalize the update, this will take approximately 3 to 5 minutes.
- The LCD will display the new version as: "**7707 FIRE V7.2.03**".

Post Subscriber Update

After the Subscriber has successfully been updated, the settings will need to be re-entered.